USER MANUAL (IN-APP, COMPLETE)

OPC UA Client

Online: mergenhub.envest.com.tr/docs/manual-opc-ua-client

Built-in QuickClient

The built-in OPC UA **client** connects to external OPC UA servers for testing and integration checks. Steps:

1. Discover	Enter the server URL (`opc.tcp://host:port/path`) → list the endpoints.
2. Endpoint & security	Pick a policy (None / Basic256Sha256) and a token (anonymous / user).
3. Connect & Browse	Walk the address space and inspect the nodes.
4. Read / Write / Subscribe	Read a value, write it, set up a live subscription.

> **Tip** If the handshake is rejected on the first attempt with a Sign&Encrypt connection, mark the remote server's certificate as "trusted" under **Settings** → **Certificates** (and, if needed, trust our own client certificate on the remote side).